




Stressless® Mary V2



You will need 6.3" behind the sofa for the Stressless® reclining function.



Max. Power Recliner Depth: 68.1

1 Seat - Left Arm	1 Seat - Center	1 Seat - Right Arm	Corner	Chair	2 Seat	3 Seat	4 Seat
Uph: 37.7" Wood: 37.1"	29.9"	Uph: 37.7" Wood: 37.1"	62.4"	Uph: 45.7" Wood: 44.1"	Uph: 75.6" Wood: 74.0"	Uph: 105.5" Wood: 103.9"	Uph: 135.4" Wood: 133.9"



Arm Options:




Upholstered



Wood

Available Modules:



NOTES:

- Mary HR seats are offered as 2 options: **Power Recline** (Leg Rest, Recline and Power Headrest) or **Stationary** (No Power). Power Recline functions can not be separated (i.e. Power Headrest is not available without Leg Rest). Corner Unit is not available with power functions.
- Arms are not removable.